

## **ExtraBolt 1-1s-1.1-1.2**

### **Installation:**

- 1)** Grease thread and head base area only (do not grease female knurling).
- 2)** Install entire ExtraBolt 1 set.
- 3)** Tight all bolts to 7-8Nm (or 5-6Nm with Loctite 243) with a T-30 Torx wrench.
- 4)** After first ride and then periodically check bolts for proper torque.



info@extralite.com