

ExtraBolt 12 Torx

Installation:

- 1) Grease thread and head base area.
- 2) Install entire ExtraBolt 12.
- 3) Tighten to 2,5-3Nm with a T-20 Torx wrench.
- 4) After first ride and then periodically
Check bolts for proper torque.



info@extralite.com