

## **ExtraBolt 14**

### **Installation:**

1) Check that your original bolts thread and length are M5x9mm as ExtraBol14.

**Warning:** if original bolts have different measures ExtraBol14 are not compatible with your derailleur.

2) Insert original washers and ExtraBol14 into front and rear derailleur threaded fittings.

3) Tighten bolts to torque (3Nm)

4) After first ride and then periodically check bolts for proper torque.

Studio Riva S.R.L. Tel. ++39-0371-203059  
Fax ++39-0371-203754

email: [info@extralite.com](mailto:info@extralite.com)  
[www.extralite.com](http://www.extralite.com)

