

ExtraBolt 2

ExtraBolt 5

Installation:

- 1)** Insert crankarms onto BB spindle.
- 2)** Install steel washers and steel BB bolts.
- 3)** Tighten left and right BB bolts (To 30Nm).
- 4)** Than the steel BB bolts and washers can be replaced with aluminum bolts (Tighten to 20Nm).
- 5)** After the first ride and than periodically check BB bolts for proper torque.

Studio Riva S.r.l. Tel: ++39-0371-203059
info@extralite.com

