

ExtraBolt 4.0-1-2

Installation:

- 1)** Put medium threadlock (loctite 243) on bolt thread only.
- 2)** Install ExtraBolt 4 and tight to 5-6Nm.

WARNING: overtightening can seriously compromise brake assembly safety.

Studio Riva S.R.L. Tel. ++39-0371-203059
Fax ++39-0371-203754

email: info@extralite.com
www.extralite.com

