

ExtraBolt 8

Installation:

- 1)** Put mid threadlock (loctite 243) on pivot thread.
- 2)** Install ExtraBolt 8 and tight to 10Nm.

Studio Riva engineering Tel/Fax: ++39-0371-203059

email: info@extralite.com
www.extralite.com

